



6 Print test label 打印测试标签

Load 4" x 4" or larger labels (with inter-label gap or continuous)*
需要 4"x4" 或更宽的标签



(b) Click on the icon
点击图标



(c) Click on the icon
点击图标



Print the sample PQ plot
打印出 PQ 测试页






* If using continuous stock, set Media Layout to Continuous at the HOME page of the touchscreen


* 如果使用连续纸, 请在触摸屏的主页上将“介质布局” (Media Layout) 设置为“连续” (Continuous).

7 Install printer driver 安装打印机驱动程序





To connect printer to computer
连接打印机到电脑



(d) Connect USB cable when prompted
按提示连接 USB



To connect printer to network
连接打印机到网络




For more information, refer to the printer User Guide
如需要详细指示, 请参考用户指南。

© 2026 VIPColor Technologies
VOSP1-80040 Edition 1



VP760 Printer / VP760打印机

Start 开始




Please download the latest printer driver from vipcolor.com to a thumb drive or into your laptop/PC connected to your printer.


请从 vipcolor.com 下载最新的打印机驱动程序到 U 盘, 或下载到连接到打印机的笔记本电脑/PC 中。

1 Remove tape and packing materials 去除胶带和包装材料




(a) Remove tapes
去除胶带




(b) Remove tapes and foam
去除胶带和泡沫保护层




(c) Remove cardboard
去除纸板



2 Connect power 连接电源



(c) Press and hold for 3 seconds
长按 3 秒



Powered by
memjet

Choose display language
选择显示语言

a

b

Click on the icon
点击图标

c

d

Click on the icon
点击图标

e

Select the language
选择语言

3 Install ink cartridges
安装墨水盒

a

b

c

d

4 Install printhead
安装打印头

a

b

c

Click on the icon
点击图标


d

Click on the icon
点击图标




Wait for printhead latch to be released
等待打印头门栓被释放。


e Open printhead latch fully
打开打印头门栓



f Remove caps
除去打印头两个蓝色帽子






g Remove printhead from packaging
从包装中取出打印头





NOTE: Keep the orange cover.
You will need it to cap the printhead
if it is removed from the printer.
保存橙色盖以便以后可盖喷头用。



Do not touch the ink couplings, electrical contacts, or nozzles.
勿触摸墨水接头, 电气触点或喷嘴




5 Load media / 装入标签




Check that ink is flowing through the tubes on both sides of the printhead.
目测检查墨水流过打印头两侧的墨水管子。



Push media roll against inner guide.
用手把标签卷筒纸往内推紧。




Flat side against media roll
塑料挡盖平面侧贴紧标签卷 (凸面侧向外)



Tighten knob fully
拧紧旋钮

f



Insert media till it stops.
Wait for printer to load media
把标签纸左边靠紧输入入口左侧, 用手平推标签到底, 同时移动右侧挡盖锁住标签, 等待打印机自动吸纸。

g

